

	LAYER 1 PRESERVATIVE	LAYER 2 PRIMER	LAYER 3 MID COAT	LAYER 4 TOPCOAT
Product	TEKNOL AQUA 1410**	ANTISTAIN AQUA 2901	AQUATOP	AQUATOP
Recommended application method	Dip / Flowcoat	Spray	Spray	Spray
Application temperature	Minimum 15°C			
Wet film thickness (µ)	N/A	150-175	150-175	150-175
Overcoat time 23°C, 50% RH	2-3 hours	4 hours	4 hours	4 hours
Action when dry		Lightly de-nib and dust off	Lightly de-nib and dust off	N/A
Equipment cleaner	Water			

*Contact Teknos for the product variant best suited to your project

**Preservative is recommended for Accoya where surface mould protection is needed

Disclaimer: The above information is normative and based on laboratory tests and practical experiences. The information is noncommittal, and we cannot accept liability for the results obtained under working conditions beyond our control, and consequently the buyer or the user is not released from the obligation to test the suitability of our products for specific means and application methods under the actual application conditions. Our liability covers only damage caused directly by defects in the products supplied by Teknos. This product is intended for professional use only. This implies that the user possesses sufficient knowledge for using the product correctly with regard to technical and working safety aspects. The latest versions of Teknos' Technical Data Sheets and Safety Data Sheets are available from our homepage www.teknos.com. All trademarks displayed on this document are the exclusive property of Teknos Group or its affiliated companies.

MAINTENANCE

FUTURA AQUA
series

Brush

Minimum 10°C

See maintenance
guidelines in the
Technical library

4 hours per coat

Water

A fully factory applied opaque coating system for Accoya.

Designed for application by automatic or manual high pressure spray.

Application Information

Apply at temperatures between 15°C and 35°C, and humidity levels below 80% RH. Low temperature and high humidity may inhibit curing.

The surface temperature must be at least 3°C above the dew point to prevent moisture condensation during the curing process.

Surfaces to be coated must be clean, dry and free from dust and grease / contaminants.

AQUATOP® opaque is available in standard and bespoke colours.

Further information

For full technical / application guidelines, visit our Technical Library via the QR code.

Specification sheets should be read in conjunction with the appropriate Factory Method Statement, which can be found in the Technical Library

Important Notes

- Light de-nibbing after the midcoat is necessary to ensure optimum film uniformity



TECHNICAL LIBRARY