

MEASURING WET FILM THICKNESS

HOW TO MEASURE WET FILM THICKNESS USING A WET FILM COMB

Step 1

Ensure the base of the coated substrate to be measured is straight.

Step 2

Choose the most appropriate measuring side of the comb.

Step 3

Place the edge of the comb directly on to the wet paint, at a 90° angle.

The comb should be 'dropped' onto the surface, not pressed onto it.

Step 4

Where the comb leaves a mark, the corresponding value on the comb represents the film thickness.

If the comb leaves marks along the whole side, move to the next side of the comb with higher values and perform step 3 again.

The film thickness is the same as the corresponding value on the comb that leaves the last mark on the paint surface.

Note that in the case of soft or uneven material the measurement result might be inaccurate.



Watch our video showing how to measure wet film thickness. Find it in the 'Coating' section of the Teknos Technical Library at [.teknos.com](https://www.teknos.com)

Always refer to the Technical Datasheet for full instructions on how to use Teknos products.

For further support, contact your local Teknos coating expert or visit [teknos.com](https://www.teknos.com)