

RENSA BRUSH
brush cleaner**PRODUCT TYPE**

RENSA BRUSH is an efficient detergent for cleaning of painting equipment for water-borne paints. Mild odour. Effectively dissolves even dried paint and keeps brushes soft.

USAGE

RENSA BRUSH is used for cleaning tools after painting work. Brushes, rollers, spraying equipment and other tools used for painting can be cleaned with RENSA BRUSH.

RENSA BRUSH is a biodegradable product. It meets the requirements by OECD and by the Detergent regulation of European Parliament and the Council on detergents for biodegradability (OECD 301B, EC 648 / 2004).

TECHNICAL DATA**pH**

abt. 11

Dilution

No dilution.

Packages
(availability varies by country)

1 L, 5 L

SAFETY MARKINGS

See Safety Data Sheet.

DIRECTION FOR USE

RENSA BRUSH is a ready-to-use solution, which is used undiluted.

Wet the tool entirely with brush cleaner, scrape off dissolved paint and rinse with clean water. Repeat if needed. If the paint has already dried, brush first off all loose paint. Then soak the tool in brush cleaner, until all the paint is dissolved.

Protection

RENSA BRUSH is an efficient, but user-friendly and biodegradable product.

However, the detergent must be used with reasonable caution.

Avoid skin contact and breathing the spray mist. **Protect eyes from splashes.**

More information from product's Safety Data Sheet: www.teknos.com

ADDITIONAL INFORMATION MUST NOT FREEZE.

The information of this data sheet is based on laboratory tests and practical experience. The figures are for guidance only and depend on, for example, colour and gloss. As we have no control over the use and application conditions, we are only responsible for the quality of the product and guarantee that it conforms to our quality control. We accept no liability for any loss or damage resulting from the application of the product contrary to the directions or the intended use. The latest versions of our data sheets, material safety data sheets and system sheets are on our home pages www.teknos.com.



EN_2251_Tuoteseloste.pdf