

APPLICATION GUIDELINES LINSEED OIL PUTTY

The oils in traditional glazing putty are slow drying and rapid overcoating can disrupt the paint film which causes premature adhesion failure. It is important to follow these guidelines when brush coating traditionally glazed windows.

1. Glaze the window or doors with putty following the manufacturer's instructions
2. Allow the surface of the putty to dry in accordance with the manufacturers instructions for paint application. This is usually between three and seven days
3. Prime all exposed surfaces of the putty with a traditional oil based solvent borne primer. Allow to thoroughly dry, ideally for a minimum of 16 hours
4. Apply two coats of the appropriate Teknos topcoat in the desired shade/colour/sheen to the primed putty surface
5. Allow to thoroughly dry

When carrying out any coating work, do not attempt to paint when the temperature is below 10°C, or if the relative humidity exceeds 80% as the curing and performance of the coating may be impaired. If there is any doubt about the substrate or underlying paint film, apply the appropriate Teknos products to a small, inconspicuous area, allow to dry for 24 hours, and inspect the appearance and adhesion to substrate. Care and maintenance products can be obtained from any of the Teknos suppliers.



For further support, contact your local Teknos coating expert or visit teknos.co.uk