

| | First Coat | Mid Coat | Top Coat |
|--------------------------------|--|----------------------------------|----------------------------------|
| Product | Aqua Primer 2907 | Aquatop 2600 translucent topcoat | Aquatop 2600 translucent topcoat |
| Recommended application method | Dip / Flow coat / Air assisted airless spray | Air assisted airless spray | Air assisted airless spray |
| Application temperature | Minimum 10°C | | |
| Wet film thickness (μ) | N/A | 150-175 | 150-175 |
| Dry film thickness (μ) | N/A | 60-70 | 60-70 |
| Overcoat time (23°C; 65% Rh) | 2-3 hours | 4 hours | 4 hours |
| Action when dry | | Lightly de nib and dust off | |
| Equipment cleaner | Water | Water | Water |

Disclaimer: The information provide in this specification sheet is for guidance only and supersedes all previous specification information. Any specification relating to the use of the products made by Teknos, whether in its technical literature, response to specific enquiry, or otherwise, is based on data believed to be reliable. The products, and information, are intended for users having requisite skill and know-how and therefore the user must satisfy themself of the suitability of the specification for the intended use. Surface and application conditions are beyond the control of Teknos and variation in environment, changes in procedures of use, or extrapolation of data, may cause unsatisfactory results.

Additional information on process control and application methods is given in Teknos' Factory Method Statements which are available from your service representative.

A fully factory applied coating system for exterior joinery, doors and windows.

Designed for application by automatic and manual air assisted airless spray unless otherwise stated

Application Information:

Apply at temperatures between 10°C and 30°C, and humidity levels below 80%. Low temperature and high humidity may inhibit curing. The surface temperature must be at least 3°C above the dew point to prevent moisture condensation during the curing process.

Aqua Primer 2907 is used to increase the protection against Blue Stain Fungi. The surface to be coated must be clean, dry and free from dust and grease. Timbers containing natural oils should be thoroughly degreased immediately prior to coating, using Teknosolv 7012 or equivalent. Failure to do so may impede drying and adhesion.

To minimise the vulnerability of exposed end grain, two brush coats of Teknoseal 4000 must be applied to exposed end grain, including machined apertures, and all construction joints sealed with v joint sealer. Please contact Teknos for further information.

Aqua Primer 2907 comes in six specially formulated colours and Aquatop 2600 translucent is available in a variety of colours, see our website or ask your representative for details.

Important notes:

1. Always apply base stain before sealing end grain and construction joints
2. Pre-treatment is only required for timer not meeting class 3 BS En 335-2
3. Teknos do not recommend the use of colourless base coats on any timber for external exposure under any circumstances.