

SYSTEM SPECIFICATION

BUILDING EXTERIORS

Opaque System for Accoya

	LAYER 1 Primer	LAYER 2 MID COAT	LAYER 3 Topcoat
Product	ANTISTAIN AQUA 2901	AQUATOP 2600-XX*	AQUATOP 2600-XX*
Recommended application method	Spray	Spray	Spray
Application temperature	Minimum 15°C		
Wet film thickness (µ)	150-175	150-175	150-175
Overcoat time 23°C, 50% RH	4 hours	4 hours	4 hours
Action when dry	Lightly de-nib and dust off N/A		N/A
Equipment cleaner	Water		

^{*}Contact Teknos for the product variant best suited to your project

Disclaimer: The above information is normative and based on laboratory tests and practical experiences. The information is noncommittal, and we cannot accept liability for the results obtained under working conditions beyond our control, and consequently the buyer or the user is not released from the obligation to test the suitability of our products for specific means and application methods under the actual application conditions. Our liability covers only damage caused directly before the products supplied by Teknos. This product is intended for professional use only. This implies that the user possesses sufficient knowledge for using the product correctly with regard to technical and working safety aspects. The latest versions of Teknos' Technical Data Sheets and Safety Data Sheets are available from our homepage www.teknos.com. All trademarks displayed on this document are the exclusive property of Teknos Group or its affiliated companies.

A fully factory applied opaque coating system for Accoya®.

Designed for application by automatic or manual high pressure spray.

Application Information

Apply at temperatures between 15°C and 35°C, and humidity levels below 80% RH. Low temperature and high humidity may inhibit curing.

The surface temperature must be at least 3°C above the dew point to prevent moisture condensation during the curing process.

The surface to be coated must be clean, dry and free from dust and grease.

AQUATOP® 2600 opaque is available in standard and bespoke colours.

Further information

Further product information can be found in the Technical Datasheets at teknos.com

Important Notes

- Light de-nibbing after the midcoat is necessary to ensure optimum film uniformity.
- Wood preservative is required for timber not meeting Class 3 EN 335-2