

	LAYER 1 SEALER	LAYER 2 MID COAT
Product	TEKNOSEAL 4002-00	AQUATOP 2600-XX*
Recommended application method	Spray	Spray
Application temperature	Minimum 15°C	
Wet film thickness (μ)	150-175	175-200
Dry film thickness (μ)	48-56	56-64
Overcoat time 23°C, 50% RH	2-3 hours	N/A
Action when dry	Lightly de-nib and dust off	
Equipment cleaner	Water	

*Contact Teknos for the product variant best suited to your project

Disclaimer: The above information is normative and based on laboratory tests and practical experiences. The information is noncommittal, and we cannot accept liability for the results obtained under working conditions beyond our control, and consequently the buyer or the user is not released from the obligation to test the suitability of our products for specific means and application methods under the actual application conditions. Our liability covers only damage caused directly by defects in the products supplied by Teknos. This product is intended for professional use only. This implies that the user possesses sufficient knowledge for using the product correctly with regard to technical and working safety aspects. The latest versions of Teknos' Technical Data Sheets and Safety Data Sheets are available from our homepage www.teknos.com. All trademarks displayed on this document are the exclusive property of Teknos Group or its affiliated companies.

A fully factory applied opaque 2-layer coating system for Tricoya®.

Designed for application by automatic or manual high pressure spray.

Application Information

Apply at temperatures between 15°C and 40°C, and humidity levels below 80% RH. Low temperature and high humidity may inhibit curing.

The surface temperature must be at least 3°C above the dew point to prevent moisture condensation during the curing process.

The surface to be coated must be clean, dry and free from dust and grease.

AQUATOP® 2600 opaque is available in standard and bespoke colours.

Further information

Further product information can be found in the Technical Datasheets at teknos.com

Important Notes

- Light de-nibbing after the midcoat is necessary to ensure optimum film uniformity.
- Pretreatment is only required for timber not meeting Class 3 EN 335-2